



Pioneer XCY Installation Guide

Triple E Technologies, LLC

Version 072618.01

Triple E Technologies, LLC
P.O. Box 2677 Post Falls, ID 83877
Phone: 208.777.9300 | Fax: 208.777.9304

© 2018 Triple E Technologies, LLC

All rights reserved. No parts of the content of this work may be reproduced or transmitted in any form without the written permission of Triple E Technologies, LLC.

The information in this document is subject to change without notice. Although Triple E Technologies, LLC has attempted to ensure the accuracy of the contents of this document, this document may include errors or omissions. The examples and sample programs are for illustration only and may not be suited to your purpose. You should verify the applicability of any example or sample program before placing the software into productive use. The examples in this document may not exactly replicate your system configuration, but the functions will remain the same.

The Triple E Technologies, LLC logo and OneTouch DataManager are registered trademarks of Triple E Technologies, LLC. All other brand names and trademarks associated with Triple E Technologies, LLC products and services are trademarks of Triple E Technologies, LLC. All other brand names and trademarks in this document are the property of their respective owners.

Comments, questions, or concerns? Please email all inquiries to helpdesk@e3tek.com

Table of Contents

Overview	1
Manufacturer Supplied Components	1
Additional Required Components	1
Hardware Identification	1
Specifications	2
Installation	3

Overview

The Pioneer will arrive fully assembled. This guide details the procedures for connecting necessary electronic components and peripherals to the unit.

Manufacturer Supplied Components

The Pioneer is shipped with the manufacturer supplied components listed below:

1. XCY MiniPC
2. Power Cord


Additional Required Components

1. Monitor and VGA Cable
2. Point of sale cable for any of the following:
 - a. Verifone Ruby/Sapphire
 - b. Verifone Pilot/Omni
 - c. Gilbarco G-Site
 - d. Gilbarco Passport
 - e. Wayne Nucleus




Hardware Identification

Front View



Rear View



1. Power button
2. USB 3.0 Ports (4)
3. COM Ports (2)
4. Audio port
5. LAN ports (2)
6. HDMI port
7. VGA port
8. DC-12V power port

Specifications

Processor	Intel 3755U or 3805U
Operating System	Windows 7 Professional 64bit
Memory	8GB RAM
Hard Drive	120GB SSD
Graphics Card	Intel® Integrated Graphics
Chassis	Bays: 1 internal 2.5"
Dimensions	1.6 x 5.2 x 4.9" (HxWxD)
Weight	1.43lbs

Installation

1. Connect keyboard and mouse USB cords to available USB ports.



2. Connect point of sale serial port to serial adaptor.



3. Ensure point of sale is powered off, then connect point of sale adaptor to available USB port.



4. Insert network cable into available LAN port, then connect the other end to network switch (not supplied).




5. Insert VGA cable into VGA port.



6. Insert AC adaptor into power port.



7. Press power button to power on Pioneer.



- END INSTALLATION -

Your Pioneer is now ready for use. Please contact Triple E Customer Support by phone at (888) 407-6077 or by email at helpdesk@e3tek.com for assistance configuring the Pioneer software.